LAS INSTRUCCIONES/INSTRUCTIONS:

1. Cerciórese que el área del reparación es limpia y seca.
2. Quite el apoyo adhesivo de MiniPatch, el centro del lugar de remiendo sobre área de reparación ***(no empuja en el centro ni directamente en área dañada)*** aire de empujón fuera de orillas de remiendo y está listo para pintar.
3. Para mejores resultados, la pintura inmediatamente.

1. Assure que la réparation est propre et sec.
2. Enlever le soutien adhésif de MiniPatch, le centre d'endroit de pièce par-dessus le domaine de réparation ***(ne pousse pas sur le centre ou directement sur le domaine endommagé)*** l'air de poussée sans bords de pièce et il est prêt à peindre.
3. Pour les meilleurs résultats, la peinture immédiatement.

INSTRUCTIONS:

1. Make sure that the repair area is clean and dry.
2. Remove adhesive backing from MiniPatch, place center of patch over repair area ***(do not push on center or directly on damaged area)*** push air out of edges of patch and it is ready to paint.
3. For best results, paint immediately.

Edges can be skimmed on smooth Flat walls for a perfect match.

To match your texture, it is best to blend with some spray texture, or go over the edges with our Match Patch.

For Indoor use only.

For more information checkout www.youtube.com/stepsavers